

How to Keep Your Air Fryer Basket

IN GREAT SHAPE



We know you'll get tons of use out of your new Air Fryer, and we want it to remain in this just-unboxed condition for as long as possible. To the right are some handy tips to prevent potential peeling and scratching.



Do NOT coat the Air Fryer Basket or Tray with cooking spray; it will cause buildup over time, which promotes sticking. If desired, brush the Tray with oil before cooking. Do NOT use metal utensils when tossing or removing food from the Air Fryer Basket. Only use plastic, wooden or silicone utensils that won't scratch the Basket or Tray.

- Take care when inserting and removing the Air Fryer Basket. Allow Basket to cool before washing. Adding cold water to the heated Basket can damage the nonstick coating.
- Clean the Air Fryer Basket and Tray by washing with soap, warm water and a non-abrasive sponge.
- Do NOT use abrasive cleaning materials, like scouring pads, because they may cause scratching or damage to the nonstick coating.
- Hand washing (even though the Basket and Tray are top-rack dishwasher safe) will increase the longevity of use.
- Gently wipe down the exterior of the Air Fryer with a damp cloth or paper towel. Never immerse the Air Fryer or its plug in water or any other liquid. The Air Fryer's housing is NOT dishwasher safe.
- After washing your Air Fryer Basket and Tray, towel dry them to ensure they're fully dry before storing. Store in a cool, dry place.

CHEFMAN®