



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

## **ILA Product # 756465 TALKING INDOOR/OUTDOOR THERMOMETER**

**FORMAT:** The item is rectangular in shape and has two digital display screens on the face of the item. Holding the item with the display screens facing up and pointing away from you, the talking speaker and small round talking button are located directly below the display screens. Holding the two side edges of the item on the opposite side of display screens, gently slide the cover of the item towards you to expose the control panel. There are two rows of buttons on the control panel indicated from left to right as follows.

**First Row:** Small round Volume Button, ON/OFF Slide Switch for HR Report, Small round HR Set Button, Small round MIN Set Button, Small round Daily MIN/MAX Button

**Second Row:** Round Mode Button, Celsius/Fahrenheit Slide Switch, Small round ALM

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

ON/OFF Button, Small round Clear Button, Small round Manual MIN/MAX Button.

On Back-side of Item on end facing away from you, there is small round hole that is used to hang the unit on wall. Above the wall mount hole is the battery compartment. Small raised bumps directly above the wall mount hole are tiny raised grips to be used to slide off battery compartment door.

## **FEATURES**

- **Voice Announcement** — Announces both indoor and outdoor temperatures in true human voice.
- **Announcement At Alarm** — Allows you to hear the temperature announcement at the pre-set alarm time.
- **Hourly Temperature Announcement** — allows you to hear the temperature every hour, except between 9:00 PM and 7:00AM (between 2100 and 700) to avoid waking you.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

- **High Temperature and Freezing Point Alerts** – Alerts you when the temperature goes above 38°C (100 °F) or below 0°C (32°F).
- **Daily High/Low Temperatures** — Allows you to find out the daily high and low temperatures.
- **Period Max/Min Temperatures** — Lets you find out the high and low temperatures for a specified time frame.
- **Volume Control and On/Off** — Allows you to either adjust or turn on and off the volume of the voice announcements
- **°C and °F** — Lets you choose what temperature scale you prefer.

## **INSTALLING THE BATTERIES**

Your thermometer is powered by two (AAA) batteries. We recommend alkaline batteries. Follow these steps to install the batteries:

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

1. Slide off the battery compartment door in the direction of the arrow, located above the raised bumps at the top rear of the unit.
2. Place two fresh (AAA) batteries in the battery compartment with the flat/negative (-) end of each battery towards the spring. If batteries are inserted correctly the unit will beep 4 times.
3. Replace the battery compartment door.
4. It is recommended that the batteries be removed if the unit is not going to be used for a long period of time.

**Notes:**

1. If the thermometer does not work after installing the batteries, try removing and re-installing them, or use new batteries.
2. If voice announcements sound weak or the display dims, replace the batteries.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

## **MOUNTING THE THERMOMETER AND REMOTE PROBE**

Your thermometer is designed to be wall or desk mounted. The indoor temperature probe is built into the unit. The out-door temperature probe (remote probe) is connected to the unit by a cable and should be placed outside the house.

### **Installation**

1. Select the location where you want to use the thermometer. If you want to wall-mount it, first drive a screw into the wall and then hang the thermometer on it using the hole on the back of the unit.
2. Route and secure the outdoor probe cable from the thermometer unit through the window to outside the house.
3. Secure the probe to the outside wall using a screw.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

## **Cautions:**

1. Do not place the thermometer or its remote probe in direct sunlight. Doing so may cause erroneous readings.
2. Keep the thermometer and the remote probe away from sources of heat or cold, such as stoves, heating and air conditioning vents, and radiators.
3. Do not place thermometer in water or anywhere it might get wet.

## **Operation**

**Adjusting the Volume** – slide open the lower cover to expose function control buttons. Press repeatedly VOLUME to select the volume of announcements and the chime. The display indicates three choices. “<<<<.” For high volume, “<<.” For low volume, and “no display” for volume off.

### **Using Mode Button**

By repeatedly pressing MODE, you can have 4 different display modes on LCD.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

1 Beep - Upper display will show Indoor temperature and Lower display will show the time.

2 Beeps – Upper display will show the Time and Lower display will show the Outdoor Temperature.

3 Beeps – Upper display will show the Time and Lower display will show the Alarm Time.

4 Beeps – Upper display will show the Indoor Temperature and Lower display will show the Outdoor Temperature.

## SETTING THE TIME

1. Press MODE repeatedly until 1 Beep is heard and the time is shown on the lower display.

2. Repeatedly press HR SET to set the current hour. The display shows PM for a PM hour. If you press and hold down the HR SET, the hour advances quickly.

3. Repeatedly press MIN SET to set the current minute. If you press and hold down MIN SET, the minute advances quickly.

4. Press MODE 4 times to hear 4 Beeps to change to indoor/outdoor temperature display mode.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**

**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

5.

## **ANNOUNCING THE CURRENT IN/OUT**

To announce the current indoor/outdoor temperature, press TALKING. The unit always announces the In/Out temperature regardless which of the four display modes you are in.

### **Turning the Hourly Announcement On or OFF**

You can set the thermometer to announce the current indoor/outdoor temperatures at the beginning of each hour.

To turn the hourly announcement, slide HR Report to On (((\*)) appears on the display. There will be no announcement between 9:00 PM and 7:00 AM (Between 21:00 and 7:00), so not to disturb your sleep.

Turn off the hourly announcement, slide HR Report switch to OFF position. To turn on slide the switch to ON position.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

## **USING THE ALARM FOR TEMPERATURE ANNOUNCEMENT**

You can have the thermometer reports the IN/OUT temperature at a preset alarm time, for example as a wake-up announcement in the morning.

Following these steps to set the alarm time.

1. Pres MODE repeatedly until “Beep, Beep, Beep” is heard and the alarm time shown on the lower display. The alarm time has a “AL” in between the hour digits and the minute digits.
2. Repeatedly press HR SET to set the alarm hour. The display shows PM for a PM hour. If you press and hold down HR SET, the hour advances quickly.
3. Repeatedly press MIN SET to set the alarm minute. If you press and hold down MIN SET the minutes advances quickly.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

4. Press MODE once to hear “Beep, Beep, Beep, Beep” and the unit returns to indoor/outdoor temperature display mode.
5. Press ALM ON/OFF repeatedly to turn on the alarm and a bell appears on the display.
6. Make sure the volume is on. There will be no announcement if the volume is set to 0. At the preset alarm time, the unit announces IN/OUT temperatures five times. Then the unit announcement, press TALKING. If you want to turn off the announcement completely, press ALM ON/OFF.

## **ANNOUNCING DAILY HIGH/LOW TEMPERATURE**

This unit records daily lowest and highest temperatures and the time at which these temperatures occur.

To hear the announcement of the highest and lowest in/out temperatures of the day, follow these steps.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

1. Press Daily MIN/MAX to announce the indoor highest temperature. The upper display shows the temperature and the lower display indicates the time at which the highest temperature occurs. DAILY MAX appears on both displays.
2. Press again DAILY MIN/MAX to announce the indoor lowest temperature. DAILY MIN appears on the display.
3. Press again DAILY MIN/MAX to announce the highest temperature. DAILY MAX appears on the display
4. Press again DAILY MIN/MAX to announce the outdoor lowest temperature. DAILY MIN appears on the display.
5. Press again DAILY MIN/MAX will return to the display mode prior to using the Daily Min/Max function.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

6. In the Daily Min/Max mode, if no button is pressed within 1 minute, the unit will automatically return to the display mode prior to using the Daily Min/Max function.

## **ANNOUNCING MANUAL MIN/MAX TEMPERATURE**

This unit records the maximum and minimum temperatures during a specific time period.

Follow these steps to use this function:

1. Press CLEAR to clear (reset) the memory and the unit will start to record the minimum and maximum temperatures from then on.
2. Press MANUAL MIN/MAX to announce the indoor lowest and highest temperatures between the time when the memory is cleared and the time when you press MANUA MIN/MAX.
3. Press again MANUAL MIN/MAX to announce the outdoor lowest and highest temperatures.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

4. Press again DAILY MIN/MAX will return to the display mode prior to using the Daily Min/Max will return to the display mode prior to using the Daily Min/Max function.

In the Manual Min/Max mode, if no button is pressed within 1 minute, the unit will automatically return to the display mode prior to using the DAILY MIN/MAX FUNCTION.

## HIGH TEMPERATURE AND FREEZING POINT ALERTS

When the indoor or outdoor temperature is above 38 degrees Celsius (100 degrees Fahrenheit) or below 0 degrees Celsius (32 degrees Fahrenheit) the unit will alert you by reporting the current outdoor and indoor temperatures three times. And unit will alert you by reporting the current outdoor and indoor temperatures three times. And a flashing dot appears on the display for temperatures above 38 degrees Celsius (100 degrees Fahrenheit) or a flashing asterisk for temperatures below 0

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**



**Customer Service Hours: 9am-5pm Eastern Time  
Monday through Friday  
Toll Free: 800-537-2118  
Local/International: 716-332-2970  
Website: [www.IndependentLiving.com](http://www.IndependentLiving.com)**

degrees Celsius (32 degrees Fahrenheit). These symbols will continue to show on the display until the temperature is back to normal.

### Selecting Celsius and Fahrenheit

The announcement as well as display can be in Celsius or Fahrenheit. Use the switch to select your choice of temperature scale.

Note: English version has voice announcement for both scales. All other languages have voice announcement for only the Celsius scale and the “Beep” sound for the Fahrenheit scale.

**Independent Living Aids, LLC**  
137 Rano Street  
[www.independentliving.com](http://www.independentliving.com)  
Buffalo, NY 14207  
Phone: 800-537-2118 716-332-2970  
873-3632

**Hours: 9am-5pm Eastern Time**  
**Website:**  
**Toll Free Fax: 855-937-3906**  
**Local/International Fax: 716-**